

“Stake in the Ground” Holding Blind

Assembly Instructions

1. Insert steel stakes into PVC poles. Install and tighten 2 bolts, washers and nuts as per drawing.
2. Slide poles into sleeves of blind from bottom openings.
3. Align metal grommet (4" from bottom of camo material) to pilot hole on PVC pole. Install screw to secure material and prevent upward movement of material on the pole.
4. To store blind: Roll into bundle like you would a map.
5. For setup: Drive stakes into the ground using your foot and body weight.
(Use of hammers may deform steel stakes so use at your best discretion.)

CAUTION: Stakes have sharp points and should be handled with care.

Hint: Erecting the blind in a straight line yields the best results for maximum coverage and stability.

