

Leg Extension Installation Instructions

The Zinger Winger™ Leg Extensions are designed to lift your winger up off the ground to allow clearance from wet or sandy conditions. They feature "quick release" button snaps which allow you to install and remove the extensions easily and quickly. If you find you do not remove the extensions after each use you may want to install them permanently using a machine bolt and locking nut (available at your local hardware store).

The extensions have 5/8" holes drilled thru them which allow you to drive "stakes" in order to hold the winger more firmly in place. This is a benefit where you will be launching a large number of birds from your winger.



Be careful when aligning and drilling the hole locations since you do not get a second chance. Some "play" or movement once the extensions are installed is normal and will not affect the performance of the winger.

This kit contains the following:

Hole Location Template
Instruction Sheet
(2) Leg Extensions

You will need the following tools:

Power Drill
5/16" Drill Bit
1/8" Drill Bit
Hammer
Measuring Tape
Pointed Punch, sharp nail or screw
1/2" flat file
Counter Sinking Bit (optional)



Instructions:

1. Clean any dirt or debris from inside the aluminum frame of the Zinger Winger™.
2. Take the attached template, fold at the seams as shown and place over frame at the top edge. (**VERY IMPORTANT**)
3. Using a punch point mark the center of the hole where you will drill. Double check the hole location before drilling the final hole.
4. Pre-drill a 1/8" hole at the center mark.
5. Insert the leg extension to see if the button top lines up properly. If so, drill a 5/16" hole being careful to maintain the centerline.
6. Run a 1/2" file over the 4 inside wall edges and the newly cut hole to remove any burrs or debris that may interfere with the extensions being inserted.
7. Insert the extension to see if the button snap engages properly. Using your drill you may need to ream the hole to a larger size to get a proper fit. Note: You have been shipped a left and right leg extension. The leg extensions are made universal by changing the direction of the button snap.
8. Optional: Countersink the holes to make it easier to depress the button snap and remove the extension.