

SURE SHOT SOUND RELEASE INSTRUCTION

To replace a new Sure Shot Sound Release only

Remove old release

1. Remove 1/8" screw from the release cover.
2. Unplug solenoid from the base
3. Unscrew all 4 screws on both sides.

Assemble new release

1. Insert all 4 screws on both sides.
2. Plug the solenoid and release cover into the base.
3. Screw in 1/8" screw tightly from the bottom.

Replacing your manual release with a remote release

1. Begin by removing the old manual release by unscrewing and saving the 4 "phillips head" machine screws.
2. Fish the new wiring harness down thru the aluminum tubing. Use the third hole from the top (left hand frame). The end of the wire will need to be fished thru a hole about 2-3 inches from the bottom. One trick to doing this is to let the wire drop right thru the end and then loop it back and fish it up from the bottom.
3. Strip approximately 1/2" of the wires plastic casing and crimp each female bullet connector to the wire end.
4. Position new release into place and finger tighten machine screws a few turns each. Do not tighten at this time.
5. LIGHTLY connect the bullet connectors and test your electronics. If the electronics attempt to "CLOSE" the trigger then you need to reverse the connectors and try again. (See Diagram).
6. Tighten down all 4 machine screws. Tuck any loose wires inside of the shield of the release.
7. If using Dogtra electronics attach the mounting plate to the receiver and install the button snaps into the female snaps. These will line up with the holes drilled on your Zinger Winger. If there is a strip of velcro type "Receiverlok" material between the 2 mounting holes you will need to strip this off in order to use the mounting plate. NOTE: You can also order a pack of matching "Receiverlok" to use with this existing mounting material.

